



GFORCE ARMS - RPX9 EXODUS 9MM BREAK-IN GUIDE

CALIBER: 9MM | ACTION: STRIKER-FIRED | BARREL: 4.02"

PURPOSE OF BREAK-IN:

YOUR RPX9 EXODUS IS PRECISION-BUILT TO DELIVER DEPENDABLE PERFORMANCE. LIKE ALL STRIKER-FIRED PLATFORMS, A PROPER BREAK-IN PERIOD IS CRITICAL TO ENSURING RELIABLE FEEDING, SMOOTHER CYCLING, AND LONG-TERM WEAR-IN OF CONTACT SURFACES BETWEEN THE SLIDE, BARREL, AND FIRE CONTROL GROUP.

RECOMMENDED BREAK-IN PROCESS:

1. Ammunition Requirements

Use high-quality, factory-loaded, brass-cased 9mm Luger (9x19mm) ammunition.

- Bullet weight: 115-147 grains
- Velocity range: 1,100-1,250 FPS
- Avoid: Steel case, remanufactured, aluminum, or low-power 'range' ammo during break-in.

2. Round Count

Fire 250-300 rounds over 1-2 sessions.

- Shoot in 3-5 round groups to allow parts to seat properly.
- Inspect and lightly re-lubricate every 50 rounds

3. Cleaning Procedure After Break-In

- Disassemble the RPX9 per the user manual.
- Clean barrel, chamber, breech face, and striker channel.
- Lubricate: Barrel hood and locking surfaces, Slide rails (frame and slide), Trigger bar and connector interface, Firing pin safety plunger. Use a high-quality synthetic lubricant or CLP.

Notes:

- Keep the pistol adequately lubricated during break-in.
- Do not install aftermarket parts until break-in is complete.
- Avoid suppressors during break-in.
- Compatible with Glock 19/17/34 magazines and most Glock 19 Gen 3 holsters.

Questions?

Visit www.gforcearms.com/support or contact us:

Email: info@gforcearms.com

Phone: (775) 788-1765