



GFORCE ARMS - GF9 RAPTURE 9MM BREAK-IN GUIDE

CALIBER: 9MM | ACTION: SEMI-AUTO | BARREL: 3.25"

PURPOSE OF BREAK-IN:

YOUR GF9 RAPTURE PISTOL IS BUILT FOR EVERYDAY CARRY AND DEPENDABLE SERVICE. AS WITH ALL NEW FIREARMS, A PROPER BREAK-IN HELPS ESTABLISH CONSISTENT RELIABILITY, SMOOTH CYCLING, AND REDUCED WEAR OVER TIME.

RECOMMENDED BREAK-IN PROCESS:

1. Ammunition Requirements

Use high-quality, factory-loaded, brass-cased 9mm Luger (9x19mm) ammunition.

- Bullet weight: 115-124 grains
- Velocity Range: 1,100–1,250 FPS
- Avoid steel case, remanufactured, or underpowered ammunition during break-in.

2. Round Count

Fire a total of 200 rounds over 1-2 sessions.

- Shoot in controlled 3-5 round strings to allow parts to settle.
- Pause every 50 rounds for quick inspection and optional re-lubrication.

3. Cleaning Procedure After Break-In

After completing 200 rounds:

- Disassemble the pistol following the user manual.
- Clean the barrel, feed ramp, breech face, slide rails, and striker channel.
- Lubricate contact points such as slide rails, barrel hood, and trigger group components.

Notes:

- Ensure the pistol remains properly lubricated throughout break-in.
- Do not modify or tune internal parts before completing the process.
- Avoid suppressors or compensators during break-in for consistent backpressure behavior.

Questions?

Visit www.gforcearms.com/support or contact us:

Email: info@gforcearms.com

Phone: (775) 788-1765